

## **Species Protective Measures for Dam and Impoundment Projects**

1. Divert stream flow around the construction area by constructing a temporary structure (dam) upstream and downstream of project area.
2. Restore damaged areas, particularly bare erodible soils, to pre-work conditions.
3. Structures must be certified by a professional engineer.
4. For new construction, an appropriate number of spillways and a minimum flow release must be constructed concurrent with construction of any dam.