

Guidelines for Aerial Delivery of Retardant or Foam near Waterways

Definitions:

WATERWAY B Any body of water including lakes, rivers, streams and ponds whether or not they contain aquatic life.

Guidelines:

These guidelines do not require the helicopter or airtanker pilot-in-command to fly in such a way as to endanger his or her aircraft, other aircraft, or structures or compromise ground personnel safety.

Avoid aerial application of retardant or foam within 300 feet of waterways.

Guidance for pilots:

To meet the 300-foot buffer zone guideline, implement the following:

- X **Medium/Heavy Airtankers:** When approaching a waterway visible to the pilot, the pilot shall terminate the application of retardant approximately 300 feet before reaching the waterway. When flying over a waterway, pilots shall wait one second after crossing the far bank or shore of a waterway before applying retardant. Pilots shall make adjustments for airspeed and ambient conditions such as wind to avoid the application of retardant within the 300-foot buffer zone.
- X **Single Engine Airtankers:** When approaching a waterway visible to the pilot, the pilot shall terminate application of retardant or foam approximately 300 feet before reaching the waterway. When flying over a waterway, pilots shall not begin application of foam or retardants until 300 feet after crossing the far bank or shore. Pilots shall make adjustments for airspeed and ambient conditions such as wind to avoid the application of retardant within the 300-foot buffer zone.
- X **Helicopters:** When approaching a waterway visible to the pilot, the pilot shall terminate the application of retardant or foams 300 feet before reaching the waterway. When flying over a waterway, pilots shall wait five seconds after crossing the far bank or shore before applying the retardant or foam. Pilots shall make adjustments for airspeed and ambient conditions such as wind to avoid the application of retardant or foam within the 300-foot buffer zone.

Exceptions:

When alternative line construction tactics are not available due to terrain constraints, congested area, life and property concerns or lack of ground personnel, it is acceptable to anchor the foam or retardant drop to the waterway. When anchoring a retardant or foam line to a waterway, use the most accurate method of delivery in order to minimize placement of retardant or foam in the waterway (e.g. a helicopter rather than a heavy

airtanker).

Deviations from these guidelines are acceptable when life or property is threatened.

When potential damage to natural resources outweighs possible loss of aquatic life, the unit administrator may approve a deviation from these guidelines.

Threatened and Endangered (T&E) Species:

The following provisions are guidance for complying with the Emergency Section 7 consultation provision of the ESA with respect to aquatic species. These provisions do not alter or diminish an action agency's responsibilities under the ESA.

Where aquatic T&E species or their habitat are potentially affected by aerial application of retardant or foam, the following additional procedures apply:

1. As soon as practicable after the aerial application of retardant or foam near waterways, determine whether the aerial application has caused any adverse effects to a T&E species or their habitat. This can be accomplished by the following:
 - a. Application of retardant or foam outside 300 ft of a waterway is presumed to avoid adverse effects on aquatic species and no further consultation for aquatic species is necessary.
 - b. Application of retardant or foam within 300 ft of a waterway requires that the unit administrator determine whether there have been any adverse effects to T&E species within the waterway.

These procedures shall be documented in the initial or subsequent fire reports.

2. If there were no adverse effects on aquatic T&E species or their habitat, there is no additional requirement to consult with Fish and Wildlife Service (FWS) or National Marine Fisheries Service (NMFS).
3. If the action agency determines that there were adverse effects on T&E species or their habitat, then the action agency must consult with FWS and NMFS as required by 50 CFR 402.05 (Emergencies). Procedures for emergency consultation are described in the Interagency Consultation Handbook, Chapter 8 (March, 1998). In the case of a long duration incident, emergency consultation should be initiated as soon as practical during the event. Otherwise, post-event consultation is appropriate. The initiation of the consultation is the responsibility of the unit administrator.

Each agency will be responsible for insuring that the appropriate guides and training manuals reflect these guidelines.